


Jet PTX & JTX Hydraulic Unit



Jet PTX & JTX Hydraulic Unit

Item	Part No.	Description
1	PTX2748-001	Handle
2	PTX2748-002	Roll Pin
3	PTX2748-003	Block Spring
4	PTX2748-004	Roll Pin
5	PTX2748-005	Roller
6	PT3348J-077	Roll Pin
7	PTX2748-008	Control Lever
8	PTX2748-009	Release Rod
	JTX2748-009	Release Rod (JTX)
9	PTX2748-010	Oil Lite Bushing
10	PTX2748-011	Roller
11	PTX2748-012	Oil Lite Bushing
12	PTX2748-013	Roller Pin
13	PTX2748-014	Roll Pin
14	PTX2748-015	Release Lever
15	TS-2311061	Hex Nut
16	TS-1503051	Socket Head Cap Screw
17	PTX2748-018	Shoulder Pin
	JTX2748-018A	Shoulder Pin (JTX)
18	PTX2748-019A	Traverse
	JTX2748-019A	Traverse (JTX)
19	PTX2748-020A	Snap Ring
20	PT2748J-081	Roll Pin
21	PTX2748-022A	Washer
22	PTX2748-023	Ball Bearing
23	PT2748A-044	Roll Pin
24	PTX2748-027A	Oil Lite Bushing
25	PTX2748-028	Handle Pin
26	PTX2748-029	Roll Pin
27	PTX2748-030	Pump Retainer Pin
28	PTX2748-031A	Washer
29	PTX2748-032A	Plunger Housing
30	A, B PTX2748-033A	U-Cup
31	A, B PTX2748-034A	Wiper
32	PTX2748-035	Spring
33	PTX2748-036	Spring Cap
34	PTX2748-037A	Plunger Piston
35	SB-6MM	Steel Ball
36	PT2748A-030	Spring Base
37	PT2748A-030A	Spring
38	PTX2748-041	Release Screw
39	A, B PTX2748-042	O-Ring
40	PTX2748-043	Pressure Adjust Screw
41	A PTX2748-045A	U-Cup
	B JTX2748-045A	U-Cup (JTX)

Item	Part No.	Description
42	A PTX2748-046	O-Ring
	B JTX2748-046A	O-Ring (JTX)
43	A PTX2748-047	Wiper
	B JTX2748-047	Wiper (JTX)
44	PTX2748-048A	Ram Piston
	JTX2748-048A	Ram Piston (JTX)
45	SB-19	Steel Ball
46	PTX2748-050	Oil Plug
47	PTX2748-051A	Pump Housing
	JTX2748-051A	Pump Housing (JTX)
	PTX2748-103	Pump Assembly
	JTX2748-103	Pump Assembly (JTX)
48	PTX2748-052A	Steer Wheel Axle
	JTX2748-052A	Steer Wheel Axle (JTX)
49	BB-6204	Bearing
50	PTX2748-054-ST	Steer Wheel Assembly, Poly on Nylon Hub W/Bearings
	PTX2748-054-HD	Steer Wheel Assembly, Poly on Aluminum Hub W/Bearings
	JTX2748-054-ST	Steer Wheel Assembly, Poly on Nylon Hub W/Bearings
	JTX2748-054-HD	Steer Wheel Assembly, Poly on Aluminum Hub W/Bearings
51	PT2748J-081A	Snap Ring
52	PTX2748-056	Hub Cap
53	PTX2748-057	Valve Cap
54	PTX2748-066	Needle Valve Spring
55	PTX2748-067	Needle Valve
56	PTX2748-071	O-Ring
57	PTX2748-068	Needle Valve Base
58	SB-7MM	Steel Ball
59	PTX2748-073	Mid-Valve Base
60	PTX2748-076	Release Valve Spring
61	PTX2748-077A	Release Valve
62	PTX2748-078A	O-Ring
63	PTX2748-079	O-Ring
64	PTX2748-080	Release Valve Housing
65	PTX2748-081	Valve Assembly (Includes Items 53-64)
66	JTX2748-105	Handle Assembly (Includes Items 1-12, 24)
	PTX2748-106	Pump/Handle/Traverse/Wheel Assembly
	JTX2748-106	Pump/Handle/Traverse/Wheel Assembly (JTX)
Kit A	PTX2748-104	Seal Kit
Kit B	JTX2748-104	Seal Kit (JTX)